
# Whirlpool

## **CABINET PARTS**




#### **CABINET PARTS**

Illus			Illus			Illus		
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	W10054150 W10054090		17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	32	8575030 8575049	Black
		Quick Start	18	8557569	Cabinet	33	8575050	Strike, Door
	W10054070	Use & Care Guide		W10045390		34		Palnut (10)
Following May Be Purchased			19	8572115		35	8565037	Door Inner
DO-IT-YOURSELF			20		Spring, Idler		8575052	
REPAIR MANUALS			21		Panel, Front	36	00.0002	Door, Outer
_				8565029			8565042	White
	LIT677818	Dryer		8565032			8575025	
_				8565031			8575024	
2		Screw, 10-16 x 1/2	22		Switch Assembly	37	0==00.4=	Door Handle
3		Screw, 8–18 x 3/8	23		Clamp, Motor		8573847	
4		Clip, Ground (2)	24	8572982	Catch, Door		W10050100	
5		Cover, Block	م ا	0570500	Assembly			Biscuit/Gold
6		Lock-Top Front (2)	25	8578560	Hole-Plug (Cabinet Base)	38 39		Seal, Front Panel Terminal Block
7 8	8558830	Panel, Rear	26	2202000	Screw, 10–16 x 1/2	39	279393	Kit (For
0	3404413	Plug-Hole	27		Screw, 8–18 x 1/2			Terminal Block)
	3404416		28	3330031	Hinge, Assembly	40	342055	Screw, 10–32 x 5/8
	3404415		20	8565018	White	41	3307650	Block, Terminal
9	8568303			W10050090		42		Pulley Assembly
9	0300303	Snap Down		W10050050		43		Belt, Drive
10	3978977	Door Switch	29		Bracket, Switch	44		Base, Motor
10	0070077	Assembly	30		Belt-Switch	45	W10002600	
11	3389420	Retainer, Idler		000000.	Jumper			6–20 x 1 1/4
12		Seal, Door	31	8533974	Screw Ground	46	8578565	Pulley, 60 HZ
13		Pal Nut (4)				47		Motor Assembly
14		Restrainer, Belt						60 HZ.
15		Clip, Front				48	238088	Hinge, Top (2)
		Panel (2)				49	8565015	Glass, Inner Door
16	3392100	Foot, Dryer				50	W10100830	Screw,
		Foot-Optional						10-16 x 3/64
		(Extended Length Package of 2)				51	18849	Pad-Top Hinge
		(Not Included)	ı			ı		

# **TOP AND CONSOLE PARTS**

For Model: WED6400SW0, WED6400SB0, WED6400SG0 (White/Grey) (Black) (Biscuit/Gold)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **TOP AND CONSOLE PARTS**

Illus	. Part	
No.	No.	DESCRIPTION
1	W10106830	Screw
2	8558863	
3	237446	
4	8563974	User Interface
5	000007.1	Panel, Console
Ū	W10110325	White
	W10110330	Black
	W10110328	Biscuit
6	3196537	Screw, 8-18 x 5/8
7	8564265	
8	W10003770	Screw, 6-19 x 3/64
9		Knob, Assembly
	8574957	White
	8574959	Black
	8574958	Biscuit
10	8572270	Assembly,
		Lint Screen
11		Cover, Lint
		Screen
	W10044320	
	W10044360	Black
	W10044330	
12	W10044470	Hinge, R.H.
4.0	W10044480	
13	W10001580	Screw
15	3395683	Connector
40		(Motor)
16	0505005	Top
	8565025 8565028	
	8565027	Black Biscuit
17	W10074270	Control,
17	W10074270	Electronic
18	3394427	Clip-Harness
19	8563853	Bracket,
.0	0000000	Machine Controller
21	337686	Screw
22	8558853	
23	8299914	
25	3936144	
26	94614	
27	3397269	Connector, Timer
		*

# **BULKHEAD PARTS**



## **BULKHEAD PARTS**

Illus. No.	Part No.	DESCRIPTION
1	8544805	Lint Chute Assembly
2 3 4	487909 3387459 347139	Screw, 8–15 x 1/2 Washer–Support
5 6 8	90767 8573836 8566498	Screw, 8–18 x 3/8 Shield, Exhaust
9	W10169881	
10	694089	
11 12 13 14 15	8577230 8546149 343641 8544801 W10053480	Housing, Blower Clip-Heater Box Screw, 10-16 x 1/2 Box, Heater Bracket,
16	3977373	Lint Chute Bracket, Drum Light
17 18 19	8573069 8544813 279457	Element, Heater Seal
20 21 22 23 24 25 26 27 28 29 30 31 32 35 36 37 38 39 40 41	489463 3196587 3406124 8558890 3402841 690997 8575325 8575324 8536973 W10001120 8576468 8557242 3934666 8557277 97787 8557272 8565688 3403634 8577274 8544810	Harness Repair) Screw, 8–18 x 5/8 Screw Bulb Bulkhead, Front Lens, Drum Light Ring Tri Shaft, (L.H.) Shaft, (R.H.) Roller, Support Nut, 3/8–16 Assembly, Sensor Bulkhead, Rear Nut 3/8–16 (R.H.) Seal Drum (2) Screw, 11–16 x 3/4 Drum, Assembly Baffle, Drum (2) Socket Assembly Thermistor

## **OPTIONAL PARTS (NOT INCLUDED)**

For Model: WED6400SW0, WED6400SB0, WED6400SG0 (White/Grey) (Black) (Biscuit/Gold)

Illus. Part

No. No. DESCRIPTION

#### **ACCESSORY PARTS**

279948 Kit,
Dryer Repair
W10071550 Dry Rack
8522199 Kit, Dryer
Vent Testing

#### PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 72032 Black

#### PAINT, PRESSURIZED SPRAY

(12 oz.)

350930 White 4392901 Biscuit 285006 Black 350938 Primer, Gray

#### PAINT, BULK (1 qt.)

799344 White (Uncut)